


## Lecture 10: Amplitude Modulation (Double Sideband *Large Carrier*, DSB-LC or AM)

Dr. Mohammed Hawa  
Electrical Engineering Department  
University of Jordan



EE421: Communications I. For more information read Chapter 4 in your textbook or visit <http://wikipedia.org/>.

### AM Modulator (Method #1)




- Three possibilities (based on the value of  $A$ ):

- Under modulation;  $m < 1$
- Critical modulation;  $m = 1$
- Over modulation;  $m > 1$






## AM Modulator (Method #2)






- Three possibilities (based on the value of  $A$ ):
  - Under modulation;  $m < 1$
  - Critical modulation;  $m = 1$
  - Over modulation;  $m > 1$

1









## Homework

If we perform AM modulation on the following baseband message signal  $m(t)$  using  $m = 0.5, 1, 2, \infty$ :

- Sketch the modulated signal in *time domain*  $\varphi_{AM}(t)$
- Sketch the *frequency domain* Fourier Transform  $\Phi_{AM}(\omega)$
- Determine the modulated signal *bandwidth*.

Copyright © Dr. Mohammed Hawa Electrical Engineering Department, University of Jordan 12

## AM Modulation Index, $m$

More power needed  
from transmitter  
(Larger  $A$ )

$$m \triangleq \frac{-m(t)_{\min}}{A}$$

$$m < 1$$

$$m = 1$$

$$m > 1$$

$$m = \infty$$

Asynchronous  
(incoherent) receivers  
can demodulate  
(Very simple and  
very inexpensive)

Only synchronous  
(coherent) receivers  
can demodulate. Such  
RX requires using a  
PLL (Expensive)



Copyright © Dr. Mohammed Hawa

Electrical Engineering Department, University of Jordan 13

## Example

Sketch the AM modulated signal in *time domain*  $\varphi_{AM}(t)$  and *frequency domain*  $\Phi_{AM}(\omega)$ , then calculate the modulated signal *bandwidth, average power, power efficiency*.



Assume the case of *tone modulation*, and:

- $m = 0.5$
- $m = 1$
- $m = 2$
- $m = \infty$



Copyright © Dr. Mohammed Hawa

Electrical Engineering Department, University of Jordan 14





## AM Average Power

$$P_{\varphi_{AM}(t)} = \overline{\varphi_{AM}^2(t)} = \lim_{T \rightarrow \infty} \frac{1}{T} \int_T \varphi_{AM}^2(t) dt$$

$$\overline{\varphi_{AM}^2(t)} = \overline{[m(t) \cos(\omega_c t) + A \cos(\omega_c t)]^2}$$

$$\overline{\varphi_{AM}^2(t)} = \overline{m^2(t) \cos^2(\omega_c t) + A^2 \cos^2(\omega_c t) + 2Am(t) \cos^2(\omega_c t)}$$

$$\overline{\varphi_{AM}^2(t)} = \overline{m^2(t) \cos^2(\omega_c t)} + A^2 \overline{\cos^2(\omega_c t)} + 2\overline{Am(t) \cos^2(\omega_c t)}$$

$$\overline{\varphi_{AM}^2(t)} = \frac{1}{2} \overline{m^2(t)} + \frac{A^2}{2} + \overline{Am(t)} = P_s + P_c + 0$$



## AM Power Efficiency

$$\eta = \frac{\text{Useful power}}{\text{Total power}} = \frac{P_s}{P_t} = \frac{P_s}{P_s + P_c}$$

$$\eta = \frac{\frac{1}{2} \overline{m^2(t)}}{\frac{1}{2} \overline{m^2(t)} + \frac{A^2}{2}} \quad (\text{general})$$

$$\eta = \frac{m^2}{m^2 + 2} \quad (\text{tone modulation})$$




## Homework #1

- A given AM (DSB-LC) broadcast station transmits an average carrier power,  $P_c$ , of 40 kW and uses a modulation index,  $m$ , of 0.707 for *tone* modulation. Assuming the antenna is represented by a  $50 \Omega$  resistive load, calculate:
  - The transmission efficiency ( $\eta$ ).
  - The total average power output ( $P_t$ ).
  - The *extra carrier* amplitude ( $A$ ).
  - The peak amplitude of the output signal.
  - *Answers:* 20%; 50 kW; 2000 V; 3414 V.



## Homework #2

- The baseband signal  $m(t)$  shown is passed through the following modulator. Assume the power efficiency is 90%,  $T = 60 \mu\text{s}$  and  $f_c = 40 \text{ MHz}$ . Determine:



## Homework #2

- Type of the modulated signal  $\phi(t)$ ?
- Bandwidth of the modulated signal?
- Average power in the sidebands  $P_s$ ?
- Average power in the extra carrier  $P_c$ ?
- Modulation index of the modulated signal?
- Magnitude spectrum density of the modulated signal  $|\Phi(\omega)|$  at  $\omega = \omega_c - 2\pi/T$ ?
- *Answers:* AM; 166.67 kHz; 18 W; 2 W; 1.5;  $2\pi \times 1.403 \delta(\omega - \omega_c + 2\pi/T)$ ;



## AM vs. DSB-SC

- Both require the same transmission bandwidth (equal to  $2B$ ).
- DSB-SC allows for a more efficient *transmitter* (power savings).
- AM allows for a cheaper *receiver* (asynchronous demodulator), while DSB-SC only works with synchronous detection.



## AM vs. QAM

- **Advantages of QAM:**
  - QAM is more bandwidth efficient than AM, allowing us to send two signals on the same channel (of bandwidth  $2B$ ).
  - QAM allows for more power efficiency at the transmitter.
- **Disadvantages of QAM:**
  - AM can be demodulated using cheap asynchronous demodulators, but QAM only works with synchronous detection (because of orthogonality).
  - There is *NO* such thing as QAM-LC.

